REPORT DOCUMENTATION PAGE

Form Approved OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.

TORM TO THE ABOVE ADDRESS.			
1. REPORT DATE (DD-MM-YYYY)	2. REPORT TYPE	3. DATES COVERED (From - To)	
September 2014	Briefing Charts	September 2014- November 2014	
4. TITLE AND SUBTITLE	5a. CONTRACT NUMBER		
		FA9300-13-C-2007	
Nanotechnology Propellant Health Monitor	5b. GRANT NUMBER		
Stakeholder Interests			
		5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)	5d. PROJECT NUMBER		
Watkins, Kenneth; McKinney, Austin		5e. TASK NUMBER	
watering, remieur, recrimey, ragun			
		5f. WORK UNIT NUMBER	
		Q10M	
7. PERFORMING ORGANIZATION NAME(8. PERFORMING ORGANIZATION REPORT NO.		
Air Force Research Laboratory (AFMC	C)		
AFRL/RQRM			
4 Draco Drive.			
Edwards AFB CA 93524-7160			
9. SPONSORING / MONITORING AGENCY		10. SPONSOR/MONITOR'S ACRONYM(S)	
Air Force Research Laboratory (AFMC	C)		
AFRL/RQR			
5 Pollux Drive.		11. SPONSOR/MONITOR'S REPORT	
Edwards AFB CA 93524-7048	NUMBER(S)		
		AFRL-RQ-ED-VG-2014-288	
12. DISTRIBUTION / AVAILABILITY STAT	EMENT		

Distribution A: Approved for Public Release; Distribution Unlimited.

13. SUPPLEMENTARY NOTES

Briefing Charts presented at Nanotechnology for Defense; Chantilly, Virginia; 10 November 2014. PA#14258

14. ABSTRACT

N/A

15. SUBJECT TERMS

16. SECURITY CLASSIFICATION OF:		17. LIMITATION OF ABSTRACT	18. NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON William Harrigan	
a. REPORT	b. ABSTRACT	c. THIS PAGE		19	19b. TELEPHONE NO
Unclassified	Unclassified	Unclassified	SAR		(include area code) 661-275-5328

Nanotechnology Propellant Health Monitoring Sensors; Success Though Multi-Stakeholder Interest





Kenneth Watkins and Austin McKinney—Polymer Aging Concepts, Inc.

NanoTechnology for Defense Conference (NT4D) 17-20 November 2014

m "

Distribution A: Approved for Public Release; Distribution Unlimited

Outline

- Introduction/PHM Challenge
- How AgeAlert PHM Sensor/Tags Work
- Stakeholder Contributions
- Where We Go From Here!

Introduction: Polymer Aging Concepts, Inc.

- Incorporated 2003, Georgia
- Lab/office in Dahlonega, GA
- 7 Employees
- Recipient of \$4M in Dept. of Energy and Dept. of Defense R&D funding
- Commercial Development Project (O&G Equipment Mfg.)

Polymer Aging Concepts, Inc. 79 Turner Rd.
Dahlonega, GA 30533
www.AgeAlert.com
kwatkins@AgeAlert.com

Partners in Development









Introduction: "The Propellant Health Monitoring (PHM) Challenge"




"Development of innovative systems to allow real-time health monitoring of solid rocket motors assessing both the current and future state.---AFRL SBIR solicitation

"Access viable approaches to cost effective, reliable service life extension testing of ordnance devices." --- MDA SBIR Solicitation

Propellant Health Monitoring (PHM): Thermal Aging Challenges


Mechanical, chemical, and physical properties of composite and NC base propellants degrade due to thermal and other environmental conditions.


Problem: Tracking these aging properties is often destructive, expensive and complex.



Ordnance thermal history may be varied and unpredictable, complicating testing schedules and life extension programs.

Propellant Thermal Aging






g. 1. Diphenylamine consumption in the single base gun propellant NC-27 – Description by a saction of shifting order. □ – 80 °C; Δ – 90 °C; ◊ – 100 °C.


Destructive testing is used to determine critical degradation parameters such as propellant elongation properties (Akbas et al., left graph) for composite propellants and stabilizer depletion (Jelisavac, right graph) for NC based propellants. (Literature examples)

Enter AgeAlert® Conductive Composite Condition Monitoring Sensors

A new non-destructive, platform technology which will tell users in *real-time* when components made of polymers have degraded to design limits









Wire & Cable Insulation



Rubber hoses




Propellants

Distribution A: Approved for Public Release; Distribution Unlimited Polymer Aging Concepts, Inc.,

What Are "Design Limits?"


Mechanical, physical, or chemical condition of the propellant which indicates <u>"living on borrowed time"</u>.




- This line (increasing failure rate) Moves with environmental changes!
- Simple "shelf life" (time) is inaccurate in complex thermal environments!

How Does AgeAlert® Work?


- Sensor is conductive composite "surrogate" of the propellant having a matrix of non-energetic propellant components and a conductive filler
- Sensor is placed in similar thermal environment as propellant; no embedment required
- Sensor resistance decreases as sensor matrix (propellant component) shrinks with time under thermal environments.






How Does AgeAlert® Work?

Since AgeAlert sensor resistance and propellant properties are both affected by similar thermally-induced chemical reactions, the resistance of AgeAlert sensors placed in same thermal environment as monitored propellant correlates to selected propellant properties that represent design end-of-life.



AgeAlert sensor resistance during thermal aging of commercial propellant provides very similar Arrhenius behavior to destructive propellant stabilizer depletion measurements

Commercial NC-Based Propellant Health Monitoring with AgeAlert Sensors




Direct (temperature independent) correlation of sensor resistance to chemical property (remaining stabilizer level)

Integration of AgeAlert Sensors and Passive RFID

Passive AgeAlert sensors integrate well with *passive* (no battery!) RFID technology:

- RFID reader provides rf energy to read tag providing tag identification and sensor resistance.
- Reader accesses algorithm to convert sensor resistance to remaining propellant life
- Passive shock (threshold) can be added
- Reader access to secure server means real time updates



Smart Shelf Life Application for Propellants: "PHM System on a Tag"

- Wired or wireless ordnance identification AND propellant condition
- Maintenance-free and <u>life of asset!</u>
- Low life cycle cost
- Easily attached to ordnance asset, tube or packaging, no embedment required
- Easily interrogated throughout life cycle without special training or complex equipment
- "Stand alone" or Integrated with current and proposed IVHM systems





Stakeholder Inputs During Development (Customer/Prime Contractor/Propellant Contractor)

- Compatibility with existing hardware/software -"Don't make me bolt or wire it in a motor!" (recertification)
- Need for field testing of prototype SSL PHM tags (Prime Contractor/Propellant Contractors)
- Variable Temperature Testing (AFRL/Prime Contractor)
- Extreme Temperature Cycling (Prime Contractor)
- Address known issues (All)
 - Sensor stability and variation
 - Wired SSL versions (HERO)
 - Temperature/humidity/shock sensitivity
 - Read range
 - Smaller/lighter
 - Manufacturability/cost
- Commercialize!!!!!





AgeAlert SSL Tag "Stakeholders"

Entity	Involvement/Instrument	Objective
AFRL	Funding (Composite Propellant Sensors)/SBIR	Development of PHM sensor/tags for composite propellants
MDA	Funding (NC Propellant Sensors)/SBIR	Development of PHM sensor/tags for NC propellants
Aerojet Rocketdyne	Consultant/Propellant Aging Contractor for AFRL/MDA	Development and testing of PHM sensor/tags for composite and NC propellants
ATK	Consultant/Propellant Aging Contractor for MDA project	Target composite propellant aging and correlation
Prime Contractor	SSL Tag testing (interest)	Possible commercialization
US Army (ARDEC, Picatinny)	Testing of NC PHM sensors, tags/CRADA	Possible PHM tag use for bulk propellant monitoring
US Army (MRDEC, Huntsville)	Testing of NC PHM tags/(Discussions)	Lab and field testing of NC PHM tags for NC propelled rockets
US Navy (NAVAIR, China Lake)	Testing of composite and NC SSL Tags/(Discussions)	Monitoring shelf life of stored rocket motors

Proposed Long Term Missile Storage Trial NAVAIR/China Lake


- Tracking new assets (relatively straightforward):
 - Attach SSL tags to new assets/containers/packaging from time they leave manufacturer.
- Track "aged" assets (tougher!):
 - Determine current aged condition:
 - NDT
 - DT of similar stored assets
 - "Extrapolation" of stored assets based on actual aging and time in service
 - Reset remaining life for each asset (reader or secure server) based on current aged condition
 - Screen remaining life with tags (reduced DT)




AgeAlert® Smart Shelf Life (SSL)Tag for Propellant Health Monitoring (PHM)




Polymer Aging Concepts, Inc. info@AgeAlert.com





• First wireless age-monitoring tag incorporating inert propellant components for accurate thermal age tracking of composite and NC-based propellants



- Passive, "inherently integrating" sensor reduces cost and complexity of propellant monitoring
- "Life of Asset", maintenance free (no batteries)
- Simple non-destructive screening identifies prematurely aged ordnance for repair/replacement
- Provides objective data in support of reliability improvement and service life extension programs
- Prototypes available for testing!





SSL Propellant Sensor/Tag



SSL Reader
Polymer Aging Concepts, Inc.,
Distribution A: Approved for Public Release; Distribution Unlimited

Field Use/Lab Data

Precise Ordnance Identification

Queries Secure Data Base for latest Algorithm

Reads % of Remaining Design Propellant Life

User Algorithm Adjustments

17

Contact Information

- Ken Watkins, Pl
- Polymer Aging Concepts, Inc.
- Mobile (706) 429-4995
- Office (706) 864-6304
- E-mail <u>kwatkins@AgeAlert.com</u>
- Web: www.AgeAlert.com

- Austin McKinney
- Polymer Aging Concepts, Inc.
- Office (706) 864-6304
- E-mail <u>amckinney@AgeAlert.com</u>
- Web: www.AgeAlert.com